



Part No. Description

- 101 Short screw shaft
- 102 Long screw shaft
- 103 Single row ball bearing
- 103-1 Single row ball bearing
- 105 Double row ball bearing
- 107 Nut
- 108 Gearwheel
- 110 Nut
- 124 Distance bush
- 132 Key
- 133 Key
- 133-1 Key
- 133-2 Locking screw
- 142 Coupling
- 142-1 Locking screw
- 144 Shaft
- 146 Nut
- 147 Bush

Part No. Description

- 310 Socket screw
- 317 Filler cap
- 318 Joint washer
- 320 Gasket
- 350 Pump casing
- 354 Socket screw
- 361 Motor bracket
- 362 Intermediate pipe
- 364 Gasket
- 364-1 Gasket
- 365 Suction basket
- 366 Socket screw
- 366-1 Socket screw
- 373 Socket screw
- 375 Fitted pin
- 375-1 Fitted pin
- 376 Fitted pin

Part No. Description

- 401 Cover
- 404 Ball bearing cover
- 406 Gearbox
- 417 Ball bearing cover
- 433 Socket screw
- 435 Socket screw
- 439 Gasket
- 440 Gasket
- 453 Plug
- 471 Tapbolt
- 475 Gasket
- 480 Anti-rotation pin for 702
- 492 Cover
- 702 Mechanical seal
- 705 V-ring
- 735 Socket screw
- 751 Glass
- 752 Gasket
- 754 Washer