

List of components

Valid for all LPE pumps, size 025/032/038. Rotor lead and Generation: D3/K3/L3/N3

With version codes: N} V} B} P} **The version code is composed of the letters in the 4 columns.**
T} Y} *Example of pump designations std: LPE 025L3 NTBP;*
option: LPE 038N3 NVBP

PosNo	Designation	Qty	Components included in spare parts set					Notes
			G012	G050	G053	G054	G057	
1020	Power rotor	1	x			x		
113	Key	1	x			x		
122	Ball bearing	1	x		x	x		
125	Secondary seal	1		x	x	x		1
202	Idler rotor	2	x			x		
351	Balancing bush	1	x			x		
401	Pump body	1						
416	Suction flange	1						
417	Screw	8						
418	Gasket to suction flange	1			x	x	x	
423	Gasket to discharge flange	1			x	x	x	
427	Discharge flange	1						
440	Return valve	1						2
451	Screw	4						
453	Screw	4						
462	Plug	1						
462A	Sealing washer	1			x	x	x	
463	Plug	1						
463A	Sealing washer	1			x	x	x	
501	Front cover	1						
506	Gasket	1			x	x	x	
509	Shaft seal	1		x	x	x		
537	Deaeration plug	2						
537A	Washer	2			x	x	x	
551	Rear cover	1						
556	Gasket	1			x	x	x	
557	Plug	1						
557A	Washer	1			x	x	x	
605	O-ring	1			x	x	x	x
608	Valve spindle	1				x		x
608A	Tension pin	1				x		x
6120	Set screw	1				x		x
613	Pin	1				x		x
614	Valve piston	1				x		x
615	Valve spring	1				x		x
(*)	Plug	1			x	x	x	
(*)	Washer	1			x	x	x	

Explanations:

G012: Rotor set
G050: Shaft seal
G053: Minor kit
G054: Major kit
G057: Joint kit
G070: Valve element

Notes:

1) Version NTxP
2) Removed from August 2011

